

PN	DESC	PRICE	UOM	COND	STOCK	QTY REQUESTED
622-2506-014	INDICATOR		EA		sales@aerodyneworldwide.com	0 <input type="text"/> <input type="button" value="Add"/>
622-2593-002	RACK		EA		sales@aerodyneworldwide.com	0 <input type="text"/> <input type="button" value="Add"/>
622-3016-001	SERVO		EA		sales@aerodyneworldwide.com	0 <input type="text"/> <input type="button" value="Add"/>
622-3363-001	VHF TRANSCEIVER		EA		sales@aerodyneworldwide.com	0 <input type="text"/> <input type="button" value="Add"/>
622-3374-002	INDICATOR, ATTITUDE DIRECTOR		EA		sales@aerodyneworldwide.com	0 <input type="text"/> <input type="button" value="Add"/>
622-3702-001	BEARING INDICATOR		EA		sales@aerodyneworldwide.com	0 <input type="text"/> <input type="button" value="Add"/>
622-3890-003	RADIO ALTIMETER		EA		sales@aerodyneworldwide.com	0 <input type="text"/> <input type="button" value="Add"/>
622-3915-001	INDICATOR		EA		sales@aerodyneworldwide.com	0 <input type="text"/> <input type="button" value="Add"/>
622-4038-001	RECEIVER-TRANSMITTER		EA		sales@aerodyneworldwide.com	0 <input type="text"/> <input type="button" value="Add"/>
622-4096-001	AMPLIFIER RADIO FREQUENCY		EA		sales@aerodyneworldwide.com	0 <input type="text"/> <input type="button" value="Add"/>
622-4298-001	INDICATOR, HORIZONTAL SITUATION		EA		sales@aerodyneworldwide.com	0 <input type="text"/> <input type="button" value="Add"/>
622-4393-002	AIR DATA COMPUTER		EA		sales@aerodyneworldwide.com	0 <input type="text"/> <input type="button" value="Add"/>
622-4394-013	AIR DATA CONTROL		EA		sales@aerodyneworldwide.com	0 <input type="text"/> <input type="button" value="Add"/>
622-4538-001	ANTENNA		EA		sales@aerodyneworldwide.com	0 <input type="text"/> <input type="button" value="Add"/>
622-4717-004	MODE CONTROL PANEL		EA		sales@aerodyneworldwide.com	0 <input type="text"/> <input type="button" value="Add"/>
622-5130-205	CONTROL PANEL		EA		sales@aerodyneworldwide.com	0 <input type="text"/> <input type="button" value="Add"/>
622-5130-801	CTL PANEL		EA		sales@aerodyneworldwide.com	0 <input type="text"/> <input type="button" value="Add"/>
622-5130-820	CONTROL UNIT-WEATHER RADAR		EA		sales@aerodyneworldwide.com	0 <input type="text"/> <input type="button" value="Add"/>
622-5132-633	WEATHER RADAR TRANSCEIVER		EA		sales@aerodyneworldwide.com	0 <input type="text"/> <input type="button" value="Add"/>
622-5135-401	ANTENNA CONTROL SUBASSEMBLY		EA		sales@aerodyneworldwide.com	0 <input type="text"/> <input type="button" value="Add"/>
622-5137-401	FLAT PLATE ANTENNA		EA		sales@aerodyneworldwide.com	0 <input type="text"/> <input type="button" value="Add"/>
622-5272-001	TRANSRECEIVER		EA		sales@aerodyneworldwide.com	0 <input type="text"/> <input type="button" value="Add"/>
622-5377-001	HF TRANSLATOR		EA		sales@aerodyneworldwide.com	0 <input type="text"/> <input type="button" value="Add"/>

622-5404-003	ANTENNA, ADF, LOOP	EA	sales@aerodyneworldwide.com	<input type="text" value="0"/>	<input type="button" value="Add"/>
622-5486-001	SELECTOR MODE	EA	sales@aerodyneworldwide.com	<input type="text" value="0"/>	<input type="button" value="Add"/>

- 1
- 5
- 6
- 7
- 8
- 9
- 10
- 16

[This page in PDF](#)

